Table 2
Pembina Valley Water Cooperative Inc.
Supplemental Groundwater Supply

Full Scale Pumping Test Monitoring Program

	Distance From Pumping Well (metres)	Instrumentation	Monitoring Frequency
LOWER SAND MO	NITORING WELLS		
TH-5A (6")		Transducer	Continuous
TH-11	369	Transducer	Continuous
TH-12	778	Transducer	Continuous
TH-19		Transducer	Continuous
TH-14	2000	Transducer	Continuous
TH-17	6000	Transducer	Continuous
TH-7	1646	Transducer	Continuous
TH-4	4500	Transducer	Continuous
OE-040		WRB Equipment	Manual
TH-1	4000	Transducer	Continuous
GSC 99-01-3	5000	Manual	Manual
GSC 99-02-3	6000	Manual	Manual
		Indiana	Iviaildai
UPPER SAND MON	NITORING WELLS		
UPPER SAND MON	NITORING WELLS	Manual	Manual
UPPER SAND MON TH-15 TH-13	19.5 2000	Manual Transducer	Manual Continuous
UPPER SAND MON TH-15 TH-13 TH-16	19.5 2000 6000	Manual Transducer Transducer	Manual Continuous Continuous
UPPER SAND MON TH-15 TH-13 TH-16 OH-034	19.5 2000 6000 2968	Manual Transducer Transducer WRB Equip	Manual Continuous Continuous Manual
UPPER SAND MON TH-15 TH-13 TH-16 OH-034	19.5 2000 6000 2968 5200	Manual Transducer Transducer WRB Equip WRB Equip	Manual Continuous Continuous Manual Manual
UPPER SAND MON TH-15 TH-13 TH-16 OH-034 OH-039 98-03	19.5 2000 6000 2968 5200 4500	Manual Transducer Transducer WRB Equip WRB Equip Transducer	Manual Continuous Continuous Manual Manual Continuous
UPPER SAND MON TH-15 TH-13 TH-16 OH-034 OH-039 98-03	19.5 2000 6000 2968 5200 4500	Manual Transducer Transducer WRB Equip WRB Equip	Manual Continuous Continuous Manual Manual
UPPER SAND MON TH-15 TH-13 TH-16 OH-034 OH-039	19.5 2000 6000 2968 5200 4500 6000	Manual Transducer Transducer WRB Equip WRB Equip Transducer	Manual Continuous Continuous Manual Manual Continuous
UPPER SAND MON TH-15 TH-13 TH-16 OH-034 OH-039 98-03 WRB 99-02	19.5 2000 6000 2968 5200 4500 6000	Manual Transducer Transducer WRB Equip WRB Equip Transducer	Manual Continuous Continuous Manual Manual Continuous
UPPER SAND MON TH-15 TH-13 TH-16 OH-034 OH-039 98-03 WRB 99-02 SANDSTONE MON	19.5 2000 6000 2968 5200 4500 6000	Manual Transducer Transducer WRB Equip WRB Equip Transducer Transducer	Manual Continuous Continuous Manual Manual Continuous Continuous Continuous